


# SIMCOM WCDMA Wireless Module

**SIM52xx\_Waking\_up\_Application\_Note\_V1.03**



<b>Document Title:</b>	SIM52xx_Waking_up_Application_Note
<b>Version:</b>	1.03
<b>Date:</b>	2010-07-19
<b>Status:</b>	Release
<b>Document Control ID:</b>	SIM52xx_Waking_up_Application_Note_V1.03

### General Notes

SIMCom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by SIMCom. The information provided is based upon requirements specifically provided to SIMCom by the customers. SIMCom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

### Copyright

This document contains proprietary technical information which is the property of SIMCom Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

*Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2010*

## Contents

Contents .....	3
Version history .....	5
1 Introduction .....	6
2 Scope of the document .....	6
3 Null modem mode of UART .....	6
3 SIM52XX wake up host (RI pin) .....	7
4 Host wake up SIM52XX (DTR pin) .....	7
5 Host wake up SIM52XX (GPIO0 pin) .....	8
6 Host wake up SIM52XX (USB/UART) .....	9

## Figure Index

FIGURE 1: NULL MODEM MODE OF SERIAL PORTS .....	6
FIGURE 2: SIM52XX WAKE UP HOST (RI PIN) .....	7
FIGURE 3: HOST WAKE UP SIM52XX (DTR PIN) .....	8
FIGURE 4: HOST WAKE UP SIM52XX (GPIO0 PIN) .....	9

## Version history

Date	Version	Description of change	Author
2010-04-06	01.00	Origin	3G team
2010-07-09	01.02	Add Change DTR wake up	Libing
2010-07-19	01.03	Modify the depiction of DTR's awakening function	Aaron

## 1 Introduction

SIM52XX can enter to sleeping mode for power saving. When SIM52XX receiving SMS or calling, it will announce the host. SIM52XX provides a waking up function to meet the requirements above. This document describes that how the host wake up SIM52XX and how SIM52XX wake up the host.

## 2 Scope of the document

This document is intended for the following versions of the SIMCOM modules

- SIM5210
- SIM5211
- SIM5213/SIM5214
- SIM5215/SIM5216
- SIM5218

## 3 Null modem mode of UART

SIM52XX provides an AT command to support Null modem. Null modem mode uses three lines (RXD, TXD GND) to setup communication between devices. The line connection is shown as below.




Figure 1: Null modem mode of serial ports

### 3 SIM52XX wake up host (RI pin)

RI pin can be used to announce or wake up host. UART of SIM52XX has 2 modes:

If serial port is used in Null Modem, the pin “RI” can be used as an interrupt pin. Normally it will stay high but in certain condition such as SMS receiving, incoming voice (CSD, video) call or URC reported, the pin “RI” will be set low to inform the master, and it will stay low until the master clear this interrupt with AT command (AT+CRIRS). If using five lines to setup communication between devices, the pin “RI” is different. First it stays high, when a voice (CSD) call coming, the pin “RI” is set to low for about 5900ms, then it is set high again about 100ms. The situation will repeat until that the call is answered or hung up. After the call is answered or hung up, the pin “RI” is set high.




Figure 2: SIM52XX wake up host (RI pin)

### 4 Host wake up SIM52XX (DTR pin)

DTR pin can be used for host to wake up SIM52XX. If serial port is used in Null Modem mode, the pin “DTR” can be used as an interrupt pin to wake up SIM52XX. The host can connect a GPIO to DTR of SIM52XX.

Normally DTR will stay high but in certain condition. When host wants to wake up SIM52XX, it can pull down DTR for about 12ms (since SIM52XX has a debounce time of 10ms for mistaken interrupt checking). Then DTR will trigger an interrupt which will finally cause SIM52XX to be waken up from sleep mode.

*Note: One can enable/disable such function by AT+CDTRISRS, also One can configure the DTR's trigger condition by AT+CDTRISRMD (only level trigger condition has debounce time). Currently the function is enabled by default and the trigger condition is low level.*

**WARNING!!!:** when DTR has been pulled down/up long enough to trigger the interrupt one


*must recover DTR to original status or the interrupt will be triggered all the time and SIM52XX may crash.*

Example:

If one wants to use DTR interrupt(level, low) to wakeup SIM52XX, then the following steps can be referred.

1. AT+CDTRISRMD=0, 0 //low level triggered interrupt
2. AT+CDTRISRS=1 //enable such function
- when one needs to wake up SIM52XX
3. pull DTR down for about 12ms.
- SIM52XX gets DTR interrupt
4. recover DTR to high state.
- SIM52XX has been awakened

**Note:** This operation is usable for SIM5215/SIM5216/SIM5218.



**Figure 3: Host wake up SIM52XX (DTR pin)**

## 5 Host wake up SIM52XX (GPIO0 pin)

Except DTR, Host can wake up SIM52XX by GPIO0. In the mode, GPIO0 should be configured as an interrupt input, not a PCM pin.






Figure 4: Host wake up SIM52XX (GPIO0 pin)

## 6 Host wake up SIM52XX (USB/UART)

If there are data receiving of SIM52XX on USB or UART, the SIM52XX can wake up also.

**Contact us:**

**Shanghai SIMCom Wireless Solutions Ltd.**

Add: Building A, SIM Technology Building, No.633, Jinzhong Road, Changning District, Shanghai, P. R. China 200335

Tel: +86 21 3235 3300

Fax: +86 21 3235 3301

URL: [www.sim.com/wm](http://www.sim.com/wm)

SIMCOM CONFIDENTIAL FILE